

Coast Guard, DHS

§ 117.1007

qualify under paragraphs (g)(1) or (g)(2) of this section.

(4) If any vessel is approaching the bridge and cannot reach the draw exactly on the hour, the drawtender may delay the opening up to ten minutes past the hour for the passage of the approaching vessel and any other vessels that are waiting to pass.

(5) Shall open on signal at all other times.

(g) The draw of the S168 bridge, mile 12 at Chesapeake (Great Bridge), shall open on signal; except that, from 6 a.m. to 7 p.m., the draw need be opened only on the hour. If any vessel is approaching the bridge and cannot reach the draw exactly on the hour, the drawtender may delay the hourly opening up to 10 minutes past the hour for the passage of the approaching vessel and any other vessels that are waiting to pass. Vessels in an emergency condition which presents danger to life or property shall be passed at any time.

(h) The draw of the Albemarle & Chesapeake Railroad bridge, mile 13.9, in Chesapeake, Virginia, shall be maintained in the open position; the draw may close only for the crossing of trains and maintenance of the bridge. When the draw is closed, a bridgetender shall be present to reopen the draw after the train has cleared the bridge.

(i) The draw of the Centerville Turnpike (SR170) bridge across the Albemarle and Chesapeake Canal, mile 15.2, at Chesapeake:

(1) Shall open on signal at any time for commercial vessels carrying liquefied flammable gas or other hazardous materials.

(2) From 6:30 a.m. to 8:30 a.m. and from 4 p.m. to 6 p.m., Monday through Friday, except Federal holidays:

(i) Need not open for the passage of recreational or commercial vessels that do not qualify under paragraph (i)(2)(ii) of this section.

(ii) Need not open for commercial cargo vessels, including tugs, and tugs with tows, unless 2 hours advance notice has been given to the Centerville Turnpike bridge at (757) 547-3632.

(3) From 8:30 a.m. to 4 p.m., Monday through Friday, except Federal holidays, the draw need only be opened on the hour and half hour.

(4) If any vessel is approaching the bridge and cannot reach the draw exactly on the hour or half hour, the drawtender may delay the opening ten minutes past the hour or half hour for the passage of the approaching vessel and any other vessels that are waiting to pass.

(5) Shall open on signal at all other times.

[CGD 82-025, 49 FR 17452, Apr. 24, 1984]

EDITORIAL NOTE: For FEDERAL REGISTER citations affecting § 117.997, see the List of CFR Sections Affected, which appears in the Finding Aids section of the printed volume and at www.fdsys.gov.

§ 117.999 Blackwater River.

The draw of the S189 bridge, mile 9.2 at South Quay, need not be opened for the passage of vessels.

[USCG-2011-0943, 77 FR 20718, Apr. 6, 2012]

§ 117.1001 Cat Point Creek.

The draw of the S634 bridge, mile 0.3 at Naylor's, need not be opened for the passage of vessels.

§ 117.1003 Chickahominy River.

The draw of the highway bridge, mile 1.5 at Barrets Ferry, shall open on signal; except that, from 11 p.m. to 7 a.m., the draw shall open on signal if at least 12 hours notice is given.

[CGD 82-025, 49 FR 17452, Apr. 24, 1984; 49 FR 37382, Sept. 24, 1984]

§ 117.1005 Chincoteague Channel.

The draw of the SR 175 Bridge, mile 3.5, at Chincoteague shall open on demand from midnight to 6 a.m., and every one and a half hours from 6 a.m. to midnight (at 6 a.m., 7:30 a.m., 9 a.m., 10:30 a.m., 12 p.m., 1:30 p.m., 3 p.m., 4:30 p.m., 6 p.m., 7:30 p.m., 9 p.m. 10:30 p.m. and midnight); except from 7 a.m. to 5 p.m. on the last consecutive Wednesday and Thursday in July, the draw need not be opened.

[CGDO5-06-002, 71 FR 66673, Nov. 16, 2006]

§ 117.1007 Elizabeth River—Eastern Branch.

(a) The draw of the Norfolk Southern Railroad Bridge (NS #V2.8), mile 2.7 at Norfolk, shall operate as follows: